



DELNORTH LANE-FLEX® FLEXIBLE BOLLARD

INSTALLATION STEPS

1. Position the Delnorth Lane-Flex® bollard in the required location and mark all three holes in position onto the surface. Note that one hole should directly face the traffic flow.
2. Drill 3 x 14mm holes to 100mm min depth.
3. Ensure the holes are free of dust and debris. Apply epoxy T-Rex, Megapoxy or approved equivalent into the holes.
4. Insert the nylon plugs into the core holes flush with the surface and apply the epoxy T-Rex to the base of the bollard around the fastening holes.
5. Place washer onto the coach screw, insert fastener through base.
6. Tighten until firm.

NOTES

1. Drawing in millimetres unless noted otherwise.
2. A Dial Before You Dig (DBYD) must be conducted where excavation is required.

A APPROVED FOR USE		DEC 2020
No	Revision	Date

Disclaimer:

The authors and sponsoring organisations shall have no liability or responsibility to the user or any other person or entity with respect to any liability, loss or damage caused or alleged to be caused, directly or indirectly, by the adoption and use of these Standard Drawings including, but not limited to, any interruption of service, loss of business or anticipatory profits, or consequential damages resulting from the use of these Standard Drawings. Persons must not rely on these Standard Drawings as the equivalent of, or a substitute for, project-specific design and assessment by an appropriately qualified professional.



DRAWING NOT TO SCALE		Drawing Title	FLEXIBLE BOLLARD
Approved	Project Services	Original Size	A3
Date	Dec. 2020	Drawing No:	CPP3513
			Rev: A